# A100 B100 C100 HD5501
## Capture  BWLOGO document

# Capture  BWLOGO

I.   Need  below toolings

```
┌──────┐                    ┌──────────┐              ┌──────────┐
│      │  USB adapter Cable │ USB serial│              │  Head    │
│  PC  │────────────────────│ port tool │──────────────│  Unit    │
│      │                    │          │              │          │
└──────┘                    └──────────┘              └──────────┘
```

## II. **Tool installation settings**；

1、 Zip-out MobaXterm_Portable_v23.0.zip， Double

click "MobaXterm_Personal_23.0.exe" （ ） icon, in zhe capture LOG interface.

# Capture BWLOGO

## II. Tool installation settings；

2、 Select： ① session → ② Serial → ③ USB serial port → ④ speed（bps）921600 → ⑤ lick OK；

# capture BWLOGO

## III. Open ADB mode;

1、After interface stop，input "SU"，click computer "enter"，display（  ）；

# Capture  BWLOGO

## III.  Open ADB mode；

2、Copy this command  " settings put global adb_enabled 1;echo "device" > /sys/class/„ dual_role_usb/dual-role-usb20/data_role                                         ‚

paste  it here  （ su console:/ # ）

## Capture BWLOGO

III. Open ADB mode；

3、Connect computer，computer device manager， display（  Android Phone ） OK;

## IV.   Computer settings；

1、Open computer properties， select "environment variables"；select " path "

# capture  BWLOGO

IV.  Computer settings；

2、 select （） file，copy folder path；

# Capture BWLOGO

## IV. Computer settings；

3、 Select "New folder path"，paste the ADB folder path，select "OK"；

# Capture BWLOGO

## V. Open ADB interface；

1、Open the computer running，input "CMD"；input "ADB"；click computer "enter"

## Capture BWLOGO

VI. Input command；

1、Input "adb root"，click computer "enter"，

# Capture BWLOGO

VI. Input command；

2、Input "adb remount"，click computer "enter"，

# Capture  BWLOGO

## VI.  Input command ；

3、Input "adb pull data/misc/bwlog" , click  computer  "enter" ,

# Capture  BWLOGO

VII.  Bwlogo  storage location;


Bwlogo location


Bwlogo and time